


1-Stamp Mode



2.Set up- Pitch 0.2mm /0.4mm/ 0.8mm/ 1.2mm (If pitch is larger, the white are of barcode will become smaller)

3. Adjust shoulder as follows

Move to right.

Move to left side and click the right arrow key.

Jorlink USA, Inc. 3714 Alliance Dr., Ste 100 Greensboro, NC 27407 Phone (336) 288-1613 www.jorlink.com support@jorlink.com Bulletin Revision Date: 03/ 17 /2021, Author Gcc.