

IFUME 400i

1704002 (90-254v)



**Hand &
Machine
Soldering**



FEATURES

- Full colour touch screen display
- Highest grade HEPA and carbon technology
- Automatic electronic flow control - maintains a constant extraction rate even as the filter blocks
- Gas and particle sensors to warn the operator
- Operate worldwide with no loss of performance

SPECIFICATIONS

Voltage	90v - 254v
Part Number	1704002
Wattage	1.1kW
Frequency	50Hz / 60Hz
Cabinet Height	1070mm
Cabinet Width	528mm
Cabinet Depth	465mm
Cabinet Weight	60Kg
Sound Level	<60dBa
Airflow	400m3/h

INCLUDED AS STANDARD...

FILTERS



**Main Filter
Code**
MPEF-113505

Description
HEPA/Chemical



**Pre-filter
Code**
MPEF-202268
Single111057

Description
F6 Labyrinth

Find out more:

 www.purexusa.com

 sales@purex.com

 **+1 (336)288-1613**

CONNECTION KIT

**Connection kit is included
see overleaf for options**

Machine Supplied With • 1 x Main Filter • 1 x Pre-filter • 1 x Connection Kit • 1 x Power Cable • 1 x Manual

OPTIONS

Main Filter

Code:	Description:
MPEF-113505H	HEPA/Chemical (Hydrophobic)
MPEF-113579	HEPA/Twin Chemical
MPEF-113668	HEPA/Twin Chemical
MPEF-113512	HEPA/Chemical (Cleanroom)
MPEF-113669	HEPA/Chemical (Cleanroom)
MPEF-113508	Chemical
MPEF-113809	HEPA
MPEF-113513	Solvent Lock

Main Filter

Code:	Description:
MPEF-113662	Chemical Special
MPEF-113505P	Chemical Special
MPEF-113531	Pleated Bag

Pre-filter

Code:	Description:
MPEF-200524	F8/F9 Pad

Connection Kits

Hose End Diameter

Hose Length

Purex Inlet Diameter

MPK-100032 50mm 3m 80mm

Connect to 50mm diameter pipe/port or Purex valve

3.0m

MPK-100043 50mm 6m 80mm

Connect to 50mm diameter pipe/port or Purex valve

6.0m

MPK-120299 80mm 3m 80mm

Connect to 80mm diameter pipe/port

3.0m

MPK-120288 100mm 2.3m 80mm

Connect to 100mm diameter pipe/port

0.3m 2.0m

MPK-120297 100mm 2m 80mm

Connect to 100mm diameter pipe/port

2.0m 2.0m


MPK-100171 125mm 3m 80mm

Connect to 125mm diameter pipe/port

3.0m

If you do not see a connection kit that fits your machine or pipework, please contact Purex or your representative

Interfacing



Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

Take a look through our Interfacing Guide to see our extensive range of options



www.purexusa.com
 sales@purexusa.com
 Jorlink Inc.
 T: (336)288-1613
 3714 Alliance Dr., Suite 100,
 Greensboro, NC 27407 USA