

Technical Data Sheet

Tel: (336) 288-1613

Solutions for CerMark ULTRA Aerosol



CerMark ULTRA is specifically formulated to laser mark on most laser markable substrates such as metals, glass, ceramics (glazed or unglazed), stone, brick (glazed & unglazed), slate and more using just one CerMark product. This new product is by far superior to our existing product line formulated to achieve the best results in the industry.

CerMark ULTRA is ethanol based which allows for a faster drying time.

Using CerMark ULTRA:

CerMark ULTRA is ready to use in aerosol can form. **IMPORTANT: Shake can well before using. Allow the agitator ball to rattle for at least 2 minutes. Failure to shake thoroughly can result in the failure of the aerosol system.** For best results, use when aerosol is between 70 and 90 degrees F.

Strengths of Product

Allows CO₂, YAG, and Fiber lasers to mark the follow substrates: Uncoated metals such as stainless, brass, aluminum and more as well as ceramics, glass, porcelain, brick and more. Produces high contrasting, highly durable marks; fast drying; will not stain sensitive metals such as brass, nickel and others.

Laser marking metals:

A variety of bare metal substrates including stainless steel, brass, aluminum, titanium, tin, copper, nickel and more.

Applying:

Clean the surface of the metal so that it is free of any type of lubricants or oils. Hold can approximately 8-12 inches from substrate to be sprayed. Depress valve fully during spray. Apply a thin coat of **CerMark ULTRA** to the metal, apply an even coating. Try to cover the area to be marked with a light spray, using two passes. For high quality results it's important for the **CerMark ULTRA** to be applied evenly across the marking area. Applying **CerMark ULTRA** may require practice to achieve the right coverage. After use, the can nozzle should be cleaned to eliminate residue to avoid a clogged nozzle. **We recommend that all CerMark ULTRA be applied in a well-ventilated area or spray booth designed to pull air away from user.**

Drying:

It is important that the **CerMark ULTRA** is allowed to dry thoroughly. It will air dry in about 2 minutes. **For best results do not force dry coated parts which includes using air blower or fan.**

Marking On metals:

A variety of bare metal substrates including stainless steel, brass, aluminum, titanium, tin, copper, nickel and more.

This step may require some trial and error to optimize your laser with a particular substrate. Keep in mind that all lasers react differently depending on the substrate, the type of laser, the laser's power, dot size, and other factors:

The following laser setting are to be considered starting points, more test marks may be necessary to optimize performance.

	25 Watt	35 Watt	50 Watt
Power	100%	90-100%	80-100%
Speed	10%	30-60%	30-80%
DPI/PPI	600/600	600/600	600/600

Marking On Aluminum & Brass:

Softer Metals require more power or slower speeds to obtain a permanent mark. We recommend at least a 50 Watt CO₂ lasers for such metals.

	Brass			Aluminum		
	25 Watt	35 Watt	50 Watt	25 Watt	35 Watt	50 Watt
Power	100%	90-100%	90-100%	100%	90-100%	90-100%
Speed	10%	10-30%	20-40%	10%	10-30%	20-40%
DPI/PPI	600/600	600/600	600/600	600/600	600/600	600/600

- Scrub test marks with 3M Scotch-Brite for verifying durability / Medium Duty Scrub Pad.
- Based on these results choose the best setting for your application.

If using a **Fiber or YAG** laser you may need to run several tests to optimize the settings for your particular laser, similar to above Testing Grid.

Laser marking non-metals:

CerMark ULTRA can be used on a variety of materials such as glass, ceramic, tile, dinnerware, mugs, stone, slate and porcelains. Results in a high contrast, smoother, blacker marks.

Applying:

Clean the marking surface so that it is free of any lubricants or contaminates. The **CerMark ULTRA** must be applied with an even coat to ensure a consistent mark and color. Hold can approximately 8-12 inches from substrate to be sprayed. Depress valve fully during spray. For optimum mark quality, an even coat of the **CerMark ULTRA** should be applied. Applying **CerMark ULTRA** will require some practice to achieve a correct and even coverage. After use, any excess material on the nozzle should be cleaned off with water.

We recommend that all CerMark products be applied in a well-ventilated area or spray booth designed to pull air away from user.
Drying:

It is important that the **CerMark ULTRA** is allowed to dry thoroughly. It will air dry in about 3 to 5 minutes. **For best results do not force dry coated parts which includes using heat lamps, air blowers or fans.**

***For higher contracting marks a second coat is recommended but allow the first coat to dry for at least 30-40 seconds.**

Recommended Starting Point for Settings:

CO2: 15%-30% power (35 watt laser)

10%-40% speed

600 DPI / 600 PPI

***Higher power output will allow for faster speed settings. This is true for all laser systems!**

Marking Notes:

Marking may require some trial and error to optimize your laser with a particular substrate. Keep in mind that all lasers react differently depending on the substrate. For more information regarding power and speed settings contact CerMark Technical Support 800-245-4951

Recommended Starting Point for Settings:

CO2: 15%-30% power (35 watt laser)
10%-40% speed
600 DPI / 600 PPI
YAG: 10-20 watts
10-20 inches/sec speed

Storage:

Do not expose to temperatures exceeding 50 degrees C / 120 degrees F.

There are solids and liquids that make up the aerosol marking products. If the aerosol can remains unused for any length of time the liquids and solids will separate, with the solids settling to the bottom of the can.

It's very important to shake the aerosol can for 2 minutes after the rattle ball inside the can has released.

After use a simple wipe of the nozzle is recommended so that products doesn't dry over the hole causing a disruption in the spray pattern.

Clean up:

Wash with water or a wet towel or sponge.

Contact Information:

To place an order or questions about properties of this product, application techniques or laser settings please call:

800-245-4951
Customer Service & Technical Service Representative

Limitation of Warranty and Liability

Ferro believes that the information contained in this document is accurate at the time of its publication. Ferro makes no warranty with respect to the information contained in this document. The information in this document is not a product specification, either in whole or in part. Your use of the information contained in this document and your purchase and use of this Ferro product are at your sole discretion. Downstream users are responsible for determination of the suitability of this product and for testing in specific applications. Nothing in this document shall be construed as a license for use that infringes upon any property rights of any third party. Please refer to the Safety Data Sheet (SDS) for safe use, handling and disposal information. All sales by Ferro to you are subject to Ferro's Terms and Conditions of Sale, as amended from time to time and available at www.ferro.com. In the event this document conflicts with Ferro's Terms and Conditions of Sale, Ferro's Terms and Conditions of Sale shall control